

Ashland

EARTHMOVERS



I-130XL2

PARTS MANUAL

ver 3-07



I-130 XL2-III

Ashland Industries Inc.
1115 Rail Drive
P.O. Box 717
Ashland, WI. 54806
Ph: 877-634-4622 Toll Free
Ph: 715-682-4622
Fx: 715-682-9717
www.ashlandind.com

MEMBER



CONSTRUCTION INDUSTRY
MANUFACTURERS ASSOCIATION





Model I-130XL Scraper

HOW TO ORDER PARTS:

IMPORTANT

Parts must be ordered through your local authorized ASHLAND dealer.

Be sure to state MODEL and SERIAL NUMBER of your machine, PART NUMBER, DESCRIPTION and QUANTITY needed.

Unless this is done, we cannot provide prompt service or assure shipment of the correct parts.



Ashland Industries weldable replacement parts are available to rebuild, modify or update your scraper to current factory specifications.


INDEX


Page 3.	Safety Guidelines
Page 4.	Operators and Maintenance Instructions
Page 5.	Illustration - Assembly
Page 6.	Illustration and Parts List - Gooseneck Frame Assembly
Page 7.	Illustration and Parts List - Apron Assembly
Page 8.	Illustration and Parts List - Bowl and Frame Assembly
Page 9.	Illustration and Parts List - Push Off Gate Assembly
Page 10.	Illustration and Parts List - Pole and Axle Assembly
Page 11.	Illustration and Parts List - Front Wheel and Hub Assembly
Page 12.	Illustration and Parts List - Rear Wheel, Spindle and Hub Assembly
Page 13-15	Illustration and Parts List - Hydraulic Cylinder, 4" x 13", Apron
Page 16.	Illustration and Parts List - Hydraulic Cylinder, 5" x 16"
Page 17.	Illustration and Parts List - Hydraulic Cylinder, 4-½" x 54"
Page 18-23	Identification, Illustration, Parts List and Adjustment - Hydraulic Valve
Page 24-28	Service Manual Appendix
Page 29-30	Troubleshooting
Page 31.	Warranty Statement




SAFETY SIGNAL WORDS

Note the use of the signal words DANGER, WARNING and CAUTION with the safety messages. The appropriate signal word for each has been selected using the following guidelines:

DANGER: Indicates an imminently hazardous situation that, if not avoided, will result in  death or serious injury. This signal word is to be limited to the most extreme situations typically for machine components which, for functional purposes, cannot be guarded.

WARNING: Indicates a potentially hazardous situation that, if not avoided, could result in  death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.

CAUTION: Indicates a potentially hazardous situation that, if not avoided, may result in  minor or moderate injury. It may also be used to alert against unsafe practices.



GENERAL SAFETY GUIDELINES

Safety of the operator is one of the main concerns in designing and developing a new piece of equipment. Designers and manufacturers build in as many safety features as possible. However, every year many accidents occur which could have been avoided by a few seconds of thought and a more careful approach to handling equipment. You, the operator, can avoid many accidents by observing the following precautions in this section. To avoid personal injury, study the following precautions and insist those working with you, or for you, follow them.

Replace any CAUTION, WARNING, DANGER or instruction safety decal that is not readable or is missing. Location of such decals is indicated in this booklet.

Do not attempt to operate this equipment under the influence of drugs or alcohol.

Review the safety instructions with all users annually.

This equipment is dangerous to children and persons unfamiliar with its operation. The operator should be a responsible adult familiar with farm machinery and trained in this equipment's operations. **Do not allow persons to operate or assemble this unit until they have read this manual and have developed a thorough understanding of the safety precautions and of how it works.**

To prevent injury or death, use a tractor equipped with a Roll Over Protective System (ROPS). Do not paint over, remove or deface any safety signs or warning decals on your equipment. Observe all safety signs and practice the instructions on them.

Never exceed the limits of a piece of machinery. If its ability to do a job, or to do so safely, is in question - **DON'T TRY IT.**


OPERATORS AND MAINTENANCE INSTRUCTIONS

This scraper is a durable piece of equipment and with proper care will yield many years of trouble free operation. The scraper requires a power source with TWO 4 way (double acting) hydraulic control valves.


The scraper should be greased at all points where grease fittings are provided. Connect hydraulic hoses to the tractor and retract lift cylinders to **REMOVE TRANSPORT LOCK PINS** (point A), then extend and retract all cylinders several times to force out any air from the hydraulic cylinders and lines. Check the oil levels in the tractor hydraulic system and add to maintain the proper level. Care should be used when adding oil or when disconnecting any oil line to keep all dirt out of the oil as dirt is a major factor in the failure of hydraulic components.

When the scraper is placed into operation, the operator will have to “feel out” the amount of depth of cut to obtain maximum loading efficiency. This is usually accomplished by taking a lesser and more uniform cut; however, some soil conditions such as loose sand may require a “pumping action” obtained by taking successive deep cuts and lifting out of cut as the tractor begins to lose power or traction.

1. After 10 hours work, all bolts should be checked and tightened if necessary.
2. Every 10 hours all grease fittings should be lubricated.
3. After 50 hours work, all bolts should be rechecked and tightened if necessary. Check wheel bearings and adjust if necessary.
4. After 300 hours work, clean and repack wheel bearings and replace, if necessary, cutting edges, worn pins, etc.




I-Series Assembly-ILL




A-13011-III

KEY NO.	PART NO.	DESCRIPTION
1	A13011	Gooseneck frame
2	AFB-00054	Bolt, 1/2" NC x 3-1/2" w/ 7500 nut
3	AHF-00028	Greasefitting 90° 1/8 NPT
4	A10152A	Pin, Frame attachment, 2" OD x 8-1/16" Long
7	AFB-00025	Bolt, 7/8" NC x 5"
8	AFN-00019	Nut, 7/8" NC
9	8125	Lockwasher, 7/8"
10	A14002	Cast socket half, rear
11	A14003	Cast socket half, front w/ zerk hole
12	A2206	Grease zerk, long shank
13	A14039	Bushing, 2.375 OD x 2.00 ID x 2"
14	OPT-00001	Long, Grease Passage
15	A030672-33	Hitch jack
16.	A125006	Dog Bone
		Safety Snap Pin

I-130XL APRON ASSEMBLY



<u>KEY NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	A123341	Apron
2	A123343	Bushing: 2" OD X 1-1/2" ID x 1-3/4" Long
3	AFB-00038	Bolt, 1-1/2" NF x 5-1/2" long
4	AFN-00018	Nut, Self lock 1-1/2" NF
5	14505	Grease fitting




A-123302-ILL

Key #	Part #	Description
1.	A123164	Bowl & Frame I-130 XL2
2.	6835	Bolt, 3/8" NC x 1" gr.5
3.	A10157 A123309-77 A123309-62L	Up To S.N. 20495: Cylinder Guard - Left Hand S.N. 20496 to S.N. 20749: Cylinder Guard - Left Hand S.N. 20750 and up Cylinder Guard - Left Hand
4.	A10158 A123309-62L	Cylinder Guard- Right Hand up to S.N. 20749 Cylinder Guard- Right Hand for S.N. 20750 and up
5.	14505	Grease Fitting
6.	7450	Nut, 3/8" NC gr. 5
7.	A123332L	Left Cutting Edge, 8" x 22-1/2" x 7/8" Hardened
8.	A123331 A123331SER	Center Cutting Edge, 8" x 22 1/2" x 7/8" Hardened Center Cutting Edge, 8" x 22 1/2" x 7/8" Hardened
9.	A12332R	Left Cutting Edge, 8" x 22-1/2" x 7/8" Hardened
10.	PB9P-NC-088-0275	Plow Bolt, 7/8" NC x 2-3/4" (12 Required)
11.	A123338L	(Optional) Left Bank Shaver Side Blade, 7/8" holes
12.	A123338R	(Optional) Right Bank Shaver Side Blade, 7/8" holes
13.	PB9P-NC-088-0275 AFN-00019	Plow Bolt, 7/8" NC x 2-3/4" (6 required per blade) Nut: 7/8" NC (6 Required per blade)
14.	AFB-00094	Flanged Bolt: 3/8 NC x 1"
15.	A12019	Greas fitting 1/4 x 28.54 Long
16.	A125026	Bulkhead Nut
17.	A123309-89	Single Hole Tab
18.	A125022	18" Grease Line

I-130XL PUSHOFF GATE


Up to S.N. 21478



KEY NO.	PART NO.	DESCRIPTION	QTY
1.	A10159	Brace (L.H. & R. H. same)	
2.	AFN-00006	Nut: 3/4" NC	
3.	AFB-00037	Bolt: 3/4" NC x 2" Lg.	
4.	AFW-00002	Lockwasher: 3/4"	
6.	7500	Nut: 1/2" NC	
7.	A10171	Dirt Shield	
8.	AFB-00019	Bolt: 1/2" x 1-1/2" NC Bolt	
9.	A16024	Pushoff Gate: Model I-130	
10.	A123306	Roller: Rear Gate	
10A.	A123307	Bushing" 1-5/8" OD x 1-1/4" ID	
10B.	A123305A	Pin: 1-1/4" x 2-3/4"	
10C.	A123353	Wear pad	
11.	AHF-00028	Grease Fitting: 1/8" NPT -90 degree	
12.	A6007A	Pin: 1-1/4" x 4-1/8" Lg.	
13.	AFP-00001	Cotter Pin: 1/4 X 3-1/2"	
14.	A10163	Bushing: 1-3/4" OD x 1-1/4" ID	
15.	A123459	V-Roller: 4-1/4 OD X 1-3/4 ID	
16.	A123323	Pin: 1-1/4 X 4 1/8" Tab Head	
17.	A10163	Bushing: 1-3/4" OD x 1-1/4" ID	
18.	A10164	Roller: 4-1/4 OD X 1-3/4 ID	
19.	A123305	Pin: 1-1/4 X 2-3/4" w/grease for Roller	
20.	8100	Lockwasher: 1/2"	
21.	AFB-00033	Bolt: 1/2 NC X 2-1/2"	
22.	A125020	32" grease line	2
23.	A123323-40	Double hole tab	2
24.	A125026	Bulkhead Nut	4
25.	A125021	54" greaseline	2
26.	A125019	grease fitting 1/4-28 .54" long	2

I-130XL PUSHOFF GATE


S.N. 21479 and up





A-10160-ILL

KEY NUMBER	PART NUMBER	DESCRIPTION
1.	A10159	Brace (L.H. & R.H. same)
2.	AFN-00006	Nut: 3/4" NC
3.	AFB-00037	Bolt: 3/4" NC x 2" Lg.
4.	AFW-00002	Lockwasher: 3/4"
6.	7500	Nut: 1/2" NC
7.	A10171	Dirt Shield
8.	AFB-00019	Bolt: 1/2" x 1-1/2" NC bolt
9.	A16024	Pushoff Gate: Model I-130
10.	A123306	Roller: Rear Gate
10A.	A123307	Bushing: 1-5/8" OD x 1-1/4" ID For Roller
10B.	A123305A	Pin: 1-1/4" x 2-3/4"
10C.	A123353	Wear Pad
12.	A6007A	Pin: 1-1/4" x 4-1/8" Lg.
13.	AFP-00001	Cotter Pin: 1/4 x 3
14.	A10163	Bushing: 1-3/4" OD x 1-1/4" ID
15.	A123459	V-Roller: 4-1/4" OD x 1-3/4" ID
16.	A123323	Pin: 1-1/4" x 4-1/8" Tab Head
17.	A10163	Bushing: 1-3/4" OD x 1-1/4" ID
18.	A10164	Roller: 4-1/4 OD x 1-3/4 ID
19.	A123305	Pin: 1-1/4 x 2-3/4" with grease for Roller
20.	810D	Lockwasher: 1/2"
21.	AFB-00033	Bolt: 1/2 NC x 2-1/2"
22.	A125020	32" grease line
23.	A123323-40	Double Hole Tab
24.	A125026	Bulkhead Nut
25.	A125021	54" greaseline
26.	A125019	Greasefitting 1/4-28 .54" long


I-130 POLE AND AXLE ASSEMBLY



A-13006-III

KEY NO.	PART NO.	DESCRIPTION
1	AFB-00018	Bolt, 1" NC x 3" lg.
2	A14017	Ball swivel
3	A14021	Spindle (weld on)
4	A13006	Pole
5	AFB-00056	Bolt, 5/16" NC x 2-1/2"
6	A14019	Pin, 1-3/4" x 7-3/8" lg.
7	A14020	Swivel hitch, double lip (optional)
8	A14020A	Swivel hitch, single lip
9	14505	Grease fitting
10	A10048	Spindle nut
11	A10049A	Lock collar
12	A10172	Nut w/lock pin
13	7430	Nut, 5/16" NC
14	AFW-00006	Lockwasher, 1"
 -A	A082875W	Yoke hitch rebuild kit - includes thrust block, thrust collar, yoke, cross shaft (6, 15, 16, 17)
15	A082875	Swivel yoke
16	A123166	Swivel block
17	A083075	Retaining Collar
 -B	A14021	Spindle (weld on) blank


FRONT WHEEL AND HUB ASSEMBLY



A-10170-III

<u>KEY NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	A14004	Hub cap
2	AFB-00080	Bolt, 5/16 NC x 1/2s lg.
3	A13007	Wheel, 18 x 16.1
4	A14015	Bearing cone (Timken 644)
5	A14014	Bearing cup (Timken 632)
6	A14010	Hub
7	A14013	Bearing cup (Timken 742)
8	A14012	Bearing cone (Timken 749)
9	A14011	Grease seal (CR 42624)
10	A10176	Stud
11	A10046	Lug nut

REAR WHEEL, SPINDLE & HUB ASSEMBLY



A-14010-ILL

KEY NO.	PART NO.	DESCRIPTION
1	A14004	Hub cap
2	AFB-00080	Bolt, 5/16 NC x 1/2 lg.
3	A10039	Wheel, 16 x 26 Drop Center
4	A14015	Bearing cone (Timken 644)
5	A14014	Bearing cup (Timken 632)
6	A14010	Hub
7	A14013	Bearing cup (Timken 742)
8	A14012	Bearing cone (Timken 749)
9	A14011	Grease seal (CR 42624)
10	A10176	Stud
11	A10046	Lug nut
12	A10048	Spindle nut
13	A10049A	Lock collar
14	A10172	Nut w/ lock pin
15	A14037	Spindle
17	AFN-00001	Nut, 1" NF Top Lock
18	AFB-00017	Bolt, 1" NF x 6-1/2" lg.

APRON CYLINDER 4"x13"



Part #A125050

s.n. 20750 and above effective 06/03

If you have 3 capscrew headcap refer to the next page.

1* OLD STYLE

The older apron cylinder can be identified by 3/8" NPT ports & 3 bolts on the headcap of the gland.




2* NEW STYLE

The new style, effective 6/25/03, has 7/8" o-ring base ports & the gland is threaded into I.D. of the barrel. Identified by the 2 holes on the end of the cylinder.

A-125050-III

ITEM	PART ITEM	DESCRIPTION
1	A125050-01	Rod 1-3/4" with welded eye
2	A125050-02	Piston
3	A125050-03	Gland, Threaded
4	A125050-04	Lock Nut, 1-1/8" NF
5	A125050-05	Seal Kit, a-f
	A125050-05a	Nylon Wear Ring
	A125050-05b	FSP Seal
	A125050-05c	O-Ring
	A125050-05d	Backup Washer
	A125050-05e	Hallite Rod Seal
	A125050-05f	Snap-in Rod Wiper
6	A123362	Pin, 1-1/2" with slot for keeper bushing
7	8602	Pin, Cotter 1/4" x 2" Zinc
8	A123363	Pin: 1-1/2" square head

HYDRAULIC CYLINDER DIG AND LIFT CIRCUIT




A-130427-ILL

CYLINDER PART NO. A516H114A

<u>KEY NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	A400H17	Lock nut, 1-1/4" NF
2	A400H04	Cast iron ring, 5" OD
3	A400H05	Backup washer, 5" OD
4	A400H06	O-ring, 5" OD x 1/4"
5	A400H07	Piston, 5" OD
6	A60H52	O-ring, 1-1/4" ID x 1/8"
7	A130H28	Shaft, 2" dia.
8	8602	Cotter pin, 1/4" x 2"
9	A123383	Pin, 1-1/4" x 7"
10	22H18A	Capscrew, 5/16" NC x 1"
11	A400H14	Wiper seal
12	A400H13	Head cap
13	A400H12	O-ring, 2" ID
14	A400H12A	Backup washer, 2" ID
15	A400H11	Retainer ring
16	A400H10	Head gland, 5" OD
17	A130H27	Barrel Assembly, 5" ID
18	14505	Grease fitting
	A400H15C	Packing kit containing:
		1 - A400H04 1 - A400H11
		2 - A400H05 1 - A400H14
		2 - A400H06 1 - A400H12
		1 - A60H52 1 - A400H12A

Up to S.N. 21462

PUSH GATE CYLINDER ASSEMBLY
4-1/2" Bore X 54" Stroke OPTIONAL




A-455H114-ILL

<u>KEY NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	
1	A175H10	Collar	
2	A130H30	2 1/2" Rod	
3	A130H29	Barrel weldment	
4	A140H13	Lock nut (2" - 12)	
5	A175H12	Piston	
6	A17506	Spacer	
7	A175H09	Head	
8	A140H07	Rod seal	
9	A140H08	Rod wiper	
10	A175H07	Wear ring	
11	A175H05	Piston seal	
12	A175H03	O-ring	
13	A175H04	Backup ring	
14	A22H15	O-ring	
15	AFB-00061	Nylon tip set screw (3/8" NC x 3/8)	16
	A175H15	Seal kit (Items 8-14)	
17	8602	Cotter pin, 1/4" x 2"	
18	A9024	Pin, 1-1/4" diameter x 4-3/4" long	19
	A14033	Pin, 1-1/4" diameter x 5" long	

I-130 Push Gate Cylinder Assembly

Part Number A125176

4 1/2" BORE X 54" STROKE



A-125176-ill

<u>KEY NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1.	A125176-10	Barrel Weldment (1)
2.	A125176-20	Shaft (1)
3.	A125176-32	Spacer (1)
4.	A125176-30	Piston (1)
5.	A125176-31	Head (1)
6.	A125175-33	1 1/4" Nylock Nut (1)
8.	A125176-40	Seal Kit (1)
9.	A125175-35	Bearing
10.	A125175-36	Snap Ring
11.	A125175-37	Grease Zerk (1)

IMPORTANT: This Hyd. Manifold was intergrated into production April, 2006
It replaces A125070 valve.
For older machines see master parts book on Ashlandind.com.

HYDRAULIC MANIFOLD ASSEMBLY

A125174

S.N. 21403 & above

SETTING THE APRON AND PUSHOFF VALVE

The manifold block containing the pushoff sequence valve cartridge and apron sequence valve cartridge is used to control two hydraulic circuits with one hydraulic remote. When the tractor hydraulic remote is activated, oil flows first to the apron cylinders until they are fully extended. Once the cylinders are fully extended, the apron circuits' hydraulic pressure begins to increase. Once the pressure threshold is surpassed (which is adjustable. See adjustment section), the sequence valve diverts the oil flow to the pushoff's hydraulic circuit. Once the push off is completely extended the operator then reverses the tractors hydraulic remote. The counterbalance valve will hold the apron open until the push off is fully retracted. The Apron sequence valve then opens and allows the apron to close.


Setting the valves:

STEP 1 PUSHOFF SEQUENCE VALVE

Loosen the lock nut (9/16") on the sequence valve cartridge. Turn the setscrew (4mm) clockwise until the front apron rises before the push-off begins to advance. (Earthmover should be empty) Turn the adjustment screw an additional 1/4 turn clockwise and tighten jam nut.

STEP 2 Counter Balance VALVE

Loosen the lock nut (9/16") on the counterbalance valve cartridge. Turn the setscrew (4mm) counter-clockwise until the apron holds in a raised position while rear gate is being retracted. Turn adjustment screw an additional 1/4 turn, tighten jam nut. DO NOT tighten adjusting screw more than necessary.




<u>ITEM #</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	A125162-01	CENTER BALANCE CARTRIDGE
2	A125162-02	SEQUENCE CARTRIDGE

HYDRAULIC VALVE IDENTIFICATION



New Valve



Old Valve


Visually there are several things you can check to ensure you have the correct valve. The new valve (shown on the left) is 6" wide whereas the older valve (shown below) was 5" wide. The new valve utilizes a unload cartridge that sticks outward on the side of the valve.



IMPORTANT: This Hyd. Manifold was intergrated into production Nov. 2003 It replaces A125055 valve which was used on S.N. 20750 to 20853. To confirm which valve you have, confirm with earlier valve I.D. page

**HYDRAULIC MANIFOLD ASSEMBLY
A125070**

S.N. 20853 & above



<u>ITEM #</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	A125070-01	DIRECTIONAL CONTROL VALVE
2	A125070-02	APRON SEQUENCE CARTRIDGE
3	A125070-03	PUSHOFF SEQUENCE CARTRIDGE
4	A125070-04	CHECK VALVE CARTRIDGE
5	A125070-05	UNLOAD CARTRIDGE

SETTING THE APRON AND PUSHOFF VALVE

The manifold block containing the pushoff sequence valve cartridge and apron sequence valve cartridge is used to control two hydraulic circuits with one hydraulic remote. When the tractor hydraulic remote is activated, oil flows first to the apron cylinders until they are fully extended. Once the cylinders are fully extended, the apron circuits' hydraulic pressure begins to increase. Once the pressure threshold is surpassed (which is adjustable. See adjustment section), the sequence valve diverts the oil flow to the pushoff's hydraulic circuit. Once the push off is completely extended the operator then reverses the tractor's hydraulic remote. The counterbalance valve will hold the apron open until the push off is fully retracted. The Apron sequence valve then opens and allows the apron to close.


Setting the valves:

STEP 1 PUSHOFF SEQUENCE VALVE

Loosen the lock nut (3/4") on the sequence valve cartridge. Turn the setscrew (1/4") clockwise until the front apron rises before the push-off begins to advance. (Earthmover should be empty) Turn the adjustment screw an additional 1/4 turn clockwise and tighten jam nut.

STEP 2 APRON SEQUENCE VALVE


Loosen the lock nut (3/4") on the counterbalance valve cartridge. Turn the setscrew (1/4") clockwise until the apron holds in a raised position while rear gate is being retracted. Turn adjustment screw an additional 1/4 turn, tighten jam nut. DO NOT tighten adjusting screw more than necessary.



IMPORTANT: This Hyd. Manifold has been replaced by A125070 on Nov 2003. To confirm which valve you have, confirm with earlier valve I.D. page


**HYDRAULIC MANIFOLD ASSEMBLY
A125055**

S.N. 20750 to 20853




<u>ITEM #</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	A125055-01	DIRECTIONAL CONTROL VALVE
2	A125055-02	COUNTER BALANCE CARTRIDGE
3	A125055-03	SEQUENCE CARTRIDGE
4	A125055-04	CHECK VALVE
5	A125055	COMPLETE ASSEMBLY WITH ALL VALVES

SEQUENCE VALVE



SEQUENCE VALVE PART #A101H47

COUNTERBALANCE



COUNTERBALANCE VALVE PART #A101H48



SEQUENCE AND COUNTERBALANCE VALVE PARTS LIST

SEQUENCE VALVE PART #A101H47 COUNTERBALANCE VALVE PART #A101H48



<u>KEY #</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	A101H49	Piston
2	A101H50	O-ring
3	A101H51	External pilot plug
4	A101H52	Orifice
5	A101H53	Plug
6	A101H54	O-ring
7	A101H55	Backup washer
*8	A101H56	Metering spool
9	A101H57	Backup washer
10	A101H58	O-ring
11	A101H59	Check seat
12	A101H60	Aluminum washer
13	A101H61	Check plug
14	A101H62	Check spring
15	A101H63	Check ball
16	A101H64	Aluminum washer
17	A101H65	Acorn nut
18	A101H66	Adjusting screw
19	A101H67	Adjusting plug - RD1075 CB
20	A101H68	Metering spring
21	A101H69	Adjusting Plug - RD1075 SM
22	A101H70	Metering Spool
*	A101H71	Valve body

* NOT SOLD SEPARATELY



Hydraulics: I-130XL2 Left Side Up to S.N. 21479



Hydraulics: I-130XL2 Right Side



Hydraulics: I-130XL2 Front



Item #	Part #	Description
1	A125070	Hydraulic Manifold assembly
2	A123391	Hydraulic Tubing, Behind Bowl, around sides
3	A123393	Hydraulic Tubing, Behind Bowl, Around Left Side
4	A123394	Hydraulic Tubing, Behind Bowl, Around Left Side
5	A123405	Hydraulic Tubing, Behind Bowl, Center
6	A123392	Hydraulic Tubing, Behind Bowl, Right Side
7	A123397	Hydraulic Tubing, Gooseneck Arm, Right Side
8	A123399	Hydraulic Tubing, Gooseneck, Straight Piece
9	A123400	Hydraulic Tubing, Gooseneck, Straight Piece
10	A123398	Hydraulic Tubing, Gooseneck Arm, Left Side
H1	A125081	1/2 X 26, High Pressure Hose
H2	A125082	1/2 X 15-1/2, High Pressure Hose
H3	A125022	18" Remote Grease Line
H4	A125084	3/4 X 15, High Pressure Hose
H5	A125085	3/4 X 59, High Pressure Hose
H6	A125086	3/4 X 11-1/2 High Pressure Hose
H7	A125087	3/4 X 19 High Pressure Hose
H8	A125088	3/4 X 67 High Pressure Hose
H9	A125089	1/2 X 20-1/2 High Pressure Hose
H10	A125090	1/2 X 29, High Pressure Hose
H11	A125091	3/4 X 59, High Pressure Hose
H12	A125093	1/2 X 19, High Pressure Hose
H13	A125093	1/2 X 24, High Pressure Hose
H14	A125094	3/4 X 20 High Pressure Hose
H15	A125095	3/4 X 19 High Pressure Hose
H16	A125096	3/4 X 22 High Pressure Hose
H17	A125073	1/2 X 138 High Pressure Hose
A	AHA-00048	90° Swivel 1-1/16 MORB X 1/2 FP
B	AHA-00041	Adapter: STRT. 3/4 M JIC X 1-1/16 MORB
C	AHA-00044	Adapter: 90° 3/4 M JIC X 1-1/16 F JIC
D	AHA-00043	Straight Swivel 1-1/16 MORRB X 1/2 FP
E	AHV-00001	Valve
F	AHA-00015	Adapter:T 3/4 M JIC X 3/4 M JIC
G	AHA-00009	Adapter: T 3/4 F P X 3/4 F P X 3/4 MP
H	AHA-00016	90° Adapter 3/4 MP X 3/4 FP
I	AHA-00010	Adapter: STRT 3/4 M JIC X 3/4 MP
J	AHA-00006	Adapter: STRT 3/4 M JIC X 3/4 MP
K	AHL-00002	Clamp: Hydraulic Tubing:2 tube
L	AHL-00001	Clamp: Hydraulic Tubing: 1 tube
M	AHA-00017	Adapter: Hex Reducer Bushing 3/4 MP X 1/2 FP
N	AHA-00021	Adapter:45° 3/4 FP X 3/4 MP
O	AHA-00020	Adapter: T 3/4 FP X 3/4 FP X 3/4 FP
P	AHL-00022	Clamp. Hyd Tubing 2 tube stacking
Q	A400H02-S	90° Swivel Adapter 1/2 MP X 1/2 FP
R	A101H72	Straight Swivel 3/4 MP X 3/4 FP

MAINTENANCE CHECKLIST

1. Grease all zerks.
 - a) Every 8 hours of operation.
 - b) See Lubrication Points section on following page.
2. Greasing the hubs.
 - a) Re-pack wheel bearings after 600 hrs of operation.
 - b) Completely clean grease out of hub and bearings every 1200 hours of operation.
3. Check tire pressure.
 - a) 20.5 - 25, 12-ply tire requires a tire pressure of 35-40 psi on a rear machine, 40-50 on a front machine.
4. Check all pins for signs of wear.
 - a) Daily
5. Check wheel lug nut torque.
 - a) After first 2 hours of operation.
 - b) Recheck daily for next 2 weeks.
 - c) Tighten wheel lug nuts in a star pattern.
 - d) Torque wheel lug nuts to 450 ft-lbs.
6. Check and retighten all bolts.
 - a) After initial 10 hours of use.
 - b) Again after 50 hours of use.
 - c) See Torque Specifications on following page.
7. Inspect cutting edges.
 - a) Daily
 - b) Replace cutting edges when center blade has been worn to approximately 6" and side edges worn to approximately 4".



CAUTION! Failure to replace worn cutting edges may result in unnecessary wear to the earthmover sides and floor.

Note: Please specify left or right "L" shaped cutting edges when ordering replacements.

TORQUE SPECIFICATIONS

<i>Grade 8</i>	
<i>Bolt</i>	<i>Torque</i>
<i>Diameter</i>	<i>ft-lbs</i>
1/4"	12
5/16"	25
3/8"	45
7/16"	70
1/2"	110
9/16"	150
5/8"	220
3/4"	380
7/8"	600
1"	900
1-1/8"	1280
Lug Nuts	750

LUBRICATION







1. Grease all zerks every 8 hrs of operation with high quality, general-purpose grease.
 - a) Grease until grease flows from around pin.

Lubrication Points (see Ill. on next page)

1. Hitch – Horizontal and vertical pins.
2. Lift Cylinders – Rod end & Trunion; Both left & right sides.
3. Front Arm Pivot Joint – Both left & right sides.
4. Apron Cylinders – Rod clevis pin; Both left & right sides.
5. Apron Pivot Pin – Both left & right sides.
6. Hold-down Rollers – Both left & right sides.
7. Floor Rollers – Both left & right sides.
8. Tapered Rollers – Both left & right sides.

Grease Locations

Grease Twice a Day



110-130-Grease locations-ill

HYDRAULIC SYSTEM

Standard Two-Circuit Hydraulic Plumbing

The apron cylinders and the push-off cylinder are controlled on the same circuit with the sequence of the operation controlled by a sequence valve. The other hydraulic circuit controls the lift cylinders on the earthmover.

***To adjust the sequence valve, see Troubleshooting section.**

Optional Three-Circuit Hydraulic Plumbing

The apron cylinders, push-off cylinder, and lift cylinders are all on separate hydraulic circuits.

PUSHING THE EARTHMOVER

The I-130XL was designed to be pushed when equipped with the optional push-bar. However, Ashland Industries, Inc. **STRONGLY** recommends using extreme caution when pushing the I-130XL earthmover to prevent any unnecessary damage.



CAUTION! The I-130XL earthmover must be pushed in a straight line with a maximum of a 100 hp dozer. Do not ram or jar the earthmover while pushing and push at a constant speed.



TROUBLESHOOTING

Introduction

With proper care and maintenance, the I-130XL will give many years of reliable service. When a situation arises where the earthmover performance is not satisfactory, this section will give some pointers on finding and correcting the problem.

Grease zerk will not take grease.

1. Grease zerk plugged.
 - a) Remove and replace grease zerk.
2. Pin is frozen.
 - a) Remove, clean, and inspect pin.
 - b) Replace pin if necessary.
3. Bushing grease passage is not aligned with grease zerk.
 - a) Remove, clean, inspect, and realign bushing.
 - b) Replace bushing if necessary and realign.

Push-off rollers do not roll.

1. The rollers need lubrication.
 - a) Check zerk hole and grease.
 - b) Remove pin, clean, inspect, and replace if necessary.
2. The roller bushing is worn out.
 - a) Remove roller assembly and replace bushing.
 - b) See parts manual.

Cylinders will not hold in preset position, i.e. the cylinder creeps.

1. Seals leaking internally.
 - a) Remove and replace seal kit.

Machine cuts unevenly.

1. Cutting edges worn unevenly.
 - a) Replace cutting edges.
2. Improperly inflated tires.
 - a) Check air pressure in tires.

Apron closes slowly

or


Apron and push-off are not working well together.

1. Sequence valve needs adjusting.
 - a) Remove acorn nut from end of sequence valve with a 1/2" wrench. Turn adjustment screw, using a 4mm hex wrench, clockwise until front apron rises before the push-off advances while the earthmover is empty. Turn the adjustment screw an additional 1/4 turn clockwise, then replace the acorn nut and tighten.
 - b) Torque check valve assembly and int. pilot plug to **25 ft-lbs maximum**.



CAUTION! Overtightening check valve assembly and int. pilot plug will cause internal damage to the sequence valve.

Note: Check valve assembly may leak slightly when torqued to 25 ft-lbs.



Limited Warranty Statement

Ashland Industries Inc. warrants each new product to be free from defects in material and workmanship. This warranty is applicable only for the normal service life expectancy of the product or components, not to exceed **six consecutive months** from the date of delivery of the new Ashland Industries product to the purchaser, or the date the product is first put into service via a rental agreement or other means, whichever occurs first.

The major components of swivel hitches used on Industrial series scrapers are warranted for three consecutive months from the date of delivery of the new Ashland Industries product to the purchaser, or the date the product is first put into service via a rental agreement or other means, whichever occurs first, except those components described below.

Genuine Ashland Industries Inc. replacement parts and components will be warranted for 30 days from date of purchase, or the remainder of the original equipment warranty period, whichever is longer.

Under no circumstances will it cover any merchandise or components thereof, which in the opinion of the company, has been subjected to misuse, unauthorized modification, alterations, an accident or if repairs have been made with parts other than those obtained through Ashland Industries Inc.

Ashland Industries Inc. in no way warrants Tires since their respective manufacturer warrants these items separately. Please call Ashland Industries Inc. to receive phone numbers of tire suppliers.

Ashland Industries Inc. in no way warrants wearable items such as cutting edges, front dolly wheel balls, socket halves, rollers, bushings, yoke hitch pins, hitch bushings, etc..

Our obligation under this warranty shall be limited to repairing or replacing, free of charge to the original purchaser, any part that, in our judgement, shall show evidence of such defect, provided further that such part shall be returned within 30 days from the date of failure to Ashland Industries Inc. routed through the dealer and distributor from whom the purchase was made, transportation charges prepaid. Upon warranty approval proper credits will be reimbursed for transportation.

This warranty shall not be interpreted to render Ashland Industries Inc. liable for injury or damages of any kind or nature to person or property. This warranty does not extend to the loss revenue, extra labor cost associated with downtime, substitute machinery, rental or for any other reason.

Except as set forth above, Ashland Industries Inc. shall have no obligation or liability of any kind on account of any of its equipment and shall not be liable for special or consequential damages. Ashland Industries Inc. make no other warranty, expressed or implied, and, specifically, Ashland Industries Inc. disclaims any implied warrant or merchantability or fitness for a particular purpose. Some states or provinces do not permit limitations or exclusions of implied warranties or incidental or consequential damages, so the limitations or exclusion in this warranty may not apply.

This warranty is subject to any existing conditions of supply which may direct affect our ability to obtain materials or manufacture replacement parts.

Ashland Industries Inc. reserves the right to make improvements in design or changes in specifications at any time, without incurring any obligation to owners of units previously sold

No one is authorized to alter, Modify or enlarge this warranty nor the exclusion, limitations and reservations.

Ashland Industries Inc.
Warranty Department